



**Compressor 4/90 Oil-free parts list**

<b>PART NO.</b>	<b>PART CODE</b>	<b>Q'ty</b>	<b>Name</b>
1	R75049001	12	Screw
2	R75049002	12	Flat washer
3	R75049003	2	Cylinder Head
4	R75049004	2	Seal
5	R75049005	4	O-Ring
6	R75049006	2	Gas-guide Tube
7	R75049007	2	Screw
8	R75049008	2	Limit Range Implement
9	R75049009	4	Valve Block
10	R75049010	2	Valve Board
11	R75049011	2	Valve plate clamp
12	R75049012	2	Screw
13	R75049013	2	O-Ring
14	R75049014	2	Cylinder
15	R75049015	2	Screw
16	R75049016	2	Valve Board
17	R75049017	2	Piston Cup
18	R75049018	2	Connecting Rod
19	R75049019	2	Wind Scooper
20	R75049020	2	circlip for shaft
21	R75049021	1	B Fan
22	R75049022	4	Shock Pad
23	R75049023	4	Screw
24	R75049024	1	Left Crankcase
25	R75049025	2	Screw
26	R75049026	2	Bearing
27	R75049027	1	Motor Rotor
28	R75049028	4	Nut
29	R75049029	1	Motor Stator
30	R75049030	4	Cushion
31	R75049031	4	Bolt
32	R75049032	4	Nut
33	R75049033	2	Power Cord Buckle
34	R75049034	1	Right Crankcase
35	R75049035	4	Screw
36	R75049036	2	Bearing
37	R75049037	2	Crank
38	R75049038	1	A Fan
39	R75049039	1	Air Filter
40	R75049040	1	Hush Pipe
41	R75049041	1	Horizontal Tank
42	R75049042	1	Regulator Valve
43	R75049043	2	Pressure Gauge
44	R75049044	2	Elbow
45	R75049045	1	Quick Connect
46	R75049046	2	Screw
47	R75049047	1	Nylon Pipe
48	R75049048	1	Soft Starter
49	R75049049	1	Elbow
50	R75049050	1	Exhaust Pipe
51	R75049051	1	Check Valve
52	R75049052	1	Pressure Switch
53	R75049053	1	Flexible Joint
54	R75049054	2	Gasket
55	R75049055	4	Screw
56	R75049056	1	Safety Valve
57	R75049057	1	Capacity Cover
58	R75049058	1	Capacity
59	R75049059	2	Screw
60	R75049060	1	protector
61	R75049061	1	Nylon Pipe
62	R75049062	2	Lining
63	R75049063	1	Cutting Sleeve
64	R75049064	1	Nut
65	R75049065	1	Ball Valve
66	R75049066	4	Foot Pad
67	R75049067	4	Bolt
68	R75049068	1	Power Cord
69	R75049069	2	Power Cord Buckle
70	R75049070	1	Handle Sleeve